



## Update Device Firmware

- Turn on Unit With FRESH Batteries
- Wait for Unit to boot fully
- Open Bottom Lid – Locate Micro USB Connector
- Plug in Micro USB Cable Into USB Port From Your Computer
- Open TRSTM Updater Application
- Browse to .dfu File
- Click Start Update
- Update takes about 2 minutes
- If Successful, Message will appear, and unit will restart

